

Typ	Numer	Pom.	Symbol	Nastawa	Aut.	dn	G	Kv	dp	Lokalizacja elementu
Z										
Z	107	101 80 80	3	0.40	15	0.012	0.241	3330	Zawór w grzejniku	
Z	106	101 80 80	3	0.37	15	0.012	0.250	3142	Zawór w grzejniku	
Z	102	101 80 80	3	0.72	15	0.010	0.155	6037	Zawór w grzejniku	
Z	102	101 80 80	3	0.74	15	0.010	0.152	6244	Zawór w grzejniku	
Z	102	101 80 80	3	0.75	15	0.010	0.151	6342	Zawór w grzejniku	
Z	102	101 80 80	3	0.68	15	0.010	0.159	5738	Zawór w grzejniku	
Z	103	101 80 80	3	0.66	15	0.009	0.148	5576	Zawór w grzejniku	
Z	101	101 80 80	4	0.49	15	0.015	0.270	4066	Zawór w grzejniku	

Wyniki - Nastawy